RCD Type LOAD CELL INSTRUCTION MANUAL

Cable connection methods.

Connection methods are shown in the < Fig 1 >. If you have misconnecting, there might be troubles with zero balance and errors on output voltage under load condition.

Maximum Admissible Excitation Voltage

(l'able 1)
Maximum Admissible Excitation Voltage (AC / DC)	20 V
Nominal Range of Excitation Voltage (AC / DC)	12 V

	Color of the core wire	Polarity	Connector Pin No.
L. L.	Red	Input (+)	A
	Black	Output(-)	. B
	O Blue	Input(-)	C
1	White	Output(+)	D
	Yellow	Shield	E
	-	4	*

Color of

Installation and Handling Cautions.

(Fig 1) Specification of Cable Connection


Set up: There are four screws (tap hole) on the Surface of bottom. When you can not fix the bolts on the bottom surface, use the installation plinth shown in < fig 2 >.

For the great performance, please pay attention to the following three facts during installation.


- ①Installation side must be 90° to the loading axis.
- ②Imposing power should go through the center of the unit.

③Use the protection unit (Stay Rod) to avoid the

loading from the side. (Fig 3)



(Fig 2) Using the installation plinth



⟨Fig 3⟩ Using the Stay Rod

Use Environment and Caution

- 1. This unit is not waterproof. Please avoid from water and moisture.
- 2. Please do not stretch or bend the cable. It might be broken. If the cable is not stable, please fix the cable.
- 3. Compensated temperature range is $-10\sim60^{\circ}\text{C}$

Maintenance


We suggest you to have a yearly maintenance and calibration (both with the extra charge) to maintain the quality of this product.

Warranty

This product has a warranty of one year after purchase. When there is any troubles or machine break down, we will repair the machine without any additional charges. But for your misuse or disassembly, then we are not responsible for the guarantee.

Please understand the situation that sometimes the machine is beyond repair due to the unlimited overload and voltage.

· Dimensional Drawing



Unit: mm

· Dimensional Chart (Unit: mm)

	Chart (Ch.		,						-	
Model	Rated	A	B	C	D	E	F	G	Н	J
	Capacity									1
RCD- 500N	500N	25	60	22	12	SR 50	36	45	42	M5 Depth 6
RCD- 1KN	1kN	25	60	22	12	SR 50	36			
RCD- 2KN	2kN	25						45	42	M5 Depth 6
	}		60	22	12	SR 50	36	45	42	M5 Depth 6
RCD 5KN	5kN	25	60	22	12	SR 50	36	45	42	M5 Depth 6
RCD- 10KN	10kN	25	60	22	12	SR 50	36	45	42	
RCD-20KN	20kN	25	60	22	$\frac{-2}{12}$	SR 50				
RCD- 50KN							36	45	42	M5 Depth 6
	50kN	40	100	35	24	SR 70	65	80	80	M8 Depth 15
RCD-100KN	100kN	40	100	35	24	SR 70	65	80	 	
RCD-200KN	200kN	45	120	40	33				80	M8 Depth 15
			120	40	იი	SR100	73	90	90	M8 Depth 15

SPECIFICATIONS	
Туре	RCD
Rated Capacity	500 N ~ 200 kN ()
Safe Overload Rating	150 %
Ultimate Overload Rating	200 %
Rated Output	2 mV/V ± 1 % (2000 × 10 ⁻⁴ strain)
Input Resistance	425 Ω
Output Resistance	350 Ω
Nominal Range of Exicitation Voltage	AC. DC. 12 V
Maximum Admissible Exicitation Voltage	AC. DC. 20 V
Linearity	± 0.15 % R.O. (500N~20kN)
	± 0.10 % R.O. (50kN~200kN)
Hysteresis	± 0.15 % R.O.
Conpensated Temperature Range	-10 ~ +60 ℃
Safe Temperature Range	-30 ~ +80 ℃
Temperature Effect on Zero Balance	± 0.01 % R.0./℃
Temperature Effect on Output	± 0.01 % /°C
Cable, Dia. &Length	φ 6 mm Four Conductor Shielded Cable 5 m (500N ~ 20kN)
	ф 8 mm Four Conductor Shielded Cable 5 m (50kN~200kN)